



Studio Microphone LIST-1			
(全スタジオ共用)			
Tube	AKG	THE TUBE	1
		C24	1
	NEUMANN	U-67	8
		U-67s	2
		M269c	4
		M49c	1
		M149	2
		U-47tube	1
	CHANDLER LIMITED	REDD Microphone	1
	Upton Microphones	Upton 251	2
	TELEFUNKEN	ELA M 251E	1
	SONY	C800G/9X	2
	VOX-O-RAMA	TYPE47	2
	MYBURGH	M1	4

**Studio Microphone LIST-2**

(全スタジオ共用)

Ribbon	COLES	4038	2
		4038(pair)	1pair
	ROYER	R-121(pair)	1pair
		SF-24	1
	BEYER	M500N	3
	RCA	77DX	1
	Altec	639A	1
Bumblebee Pro	RM-7	1pair	

Dynamic	Electro-Voice	RE20	2
	SHURE	SM57	14
		SM58	4
		BETA52A	2
	AKG	D112	3
		D12	1
	audio-technica	ATM25	4
		ATM63HE	1
		HYP-180B	1
	SENNHEISER	MD421	13
		MD421 SE(GOLD)	4
		MD422	6
MD441		4	

DI	COUNTRYMAN	Type85	6
	BSS	AR116	3
	AVALON	U-5	3
	Marinair	Freedom	2
	REAMP	REAMP(Black)	2



Studio Microphone LIST-3			
(全スタジオ共用)			
Condenser	AKG	C414	4
		C414EB(FREEDOM Original)	1
		C414B XLS(Pair)	2Pair
		C414B XLS	3
		C451E	5
		C451EB	3
		C451B(Pair)	1Pair
		C408(MicroMIC)	1
	B&K	4006	2
		4011	3
	MBHO	MBC603	2
	NEUMANN	U-87i	5
		U-87Ai	2
		KM86i	3
		U-47fet	4
	SCHOEPS	CMC-55U	2
		BLM 03 C	2
		V4 U	1
	SONY	C37P	2
		C38B	3
	SHURE	A98SPM	1
	Josephson	C42	1